

Tabla de Contenido

How to replace the Belt Tensioner Pulley


(CORE One)	3
Paso 1 - Introduction	4
Paso 2 - Tools necessary for this guide	5
Paso 3 - Printer Preparation	5
Paso 4 - Tensioner Pulley Info	6
Paso 5 - Tensioner Pulley Removal	6
Paso 6 - Pulley Assembly Disassembly	7
Paso 7 - Belt-Tensioner-Pulley Preparation	7
Paso 8 - Tensioner Preparation	8
Paso 9 - Pulley Assembly	9
Paso 10 - Tensioning Bolt Lubrication	10
Paso 11 - Tensioner Installation	11
Paso 12 - Belt Tensioning	11
Paso 13 - Finish	12

How to replace the Belt Tensioner Pulley (CORE One)



help.prusa3d.com/g948770

Escanea el código
QR para ver la última
versión de este
capítulo.



PASO 1 Introduction



● This guide will take you through the **Belt-tensioner-pulley** assembly replacement on your Prusa **CORE One**.

● Todas las piezas necesarias están disponibles en nuestra tienda prusa3d.com.




Ten en cuenta que debes iniciar sesión para tener acceso a la sección de repuestos.



Advertencia: En esta guía manipularás chapas metálicas. ¡¡Ten cuidado!!

PASO 2 Tools necessary for this guide



● Por favor prepara las herramientas para este guía:

● 2.5mm Allen key

● Prusa lubricant or another suitable grease (available in e-shop)

PASO 3 Printer Preparation



● En la impresora, ve al menú **Control** y selecciona **Auto Home**.

● Apaga la impresora mediante el interruptor situado en la parte posterior.

● Desconecta la impresora de la corriente.

PASO 4 Tensioner Pulley Info



- There are two belt tensioner pulleys on each side.


i In this guide, we demonstrate the replacement of the component on the right side of the printer, but the process is the same for the left side as well.

PASO 5 Tensioner Pulley Removal




- Fully loosen the belt tensioning screw.
- On the inside of the printer, pull by the belt to disengage the belt-tensioner-pulley assembly.

PASO 6 Pulley Assembly Disassembly



- On the pulley assembly, remove the M3x18 screw.
- The plastic part and the GT2-20 Idler Pulley will separate.
- Remove the GT2-20 Idler Pulley from the belt.

PASO 7 Belt-Tensioner-Pulley Preparation



● **Para los siguientes pasos, prepara:**


- Belt-tensioner-pulley plastic part (1x)
- M3nS nut (1x)
- M3x18 screw (1x)
- GT2-20 Idler Pulley (1x)

PASO 8 Tensioner Preparation



- ⬢ Note that the Belt-tensioner-pulley part has "R" and "L" markings; for use on the right side, ensure the "R" is facing up, and for the left side, the "L" should face up.
- ⬢ Insert the M3nS nut into the corresponding opening in the plastic part and push it all the way in.

PASO 9 Pulley Assembly



- Hook the Idler Pulley by the belt on the inside of the printer.

 **Make sure the belt is straight and not twisted!**

- Attach the Belt-tensioner-pulley plastic part onto the pulley itself.


 **Make sure the part with the nut is pointing towards the center of the printer!!**

- Align both parts and fix them together using the M3x18 screw.

 Tighten the screw.

 There should be either the "R" or "L" marking visible on top, depending on the side you are working on.

PASO 10 Tensioning Bolt Lubrication



- Before re-installing the M3x30 **belt tensioning bolt**, it should be lubricated to ensure smooth belt adjustment and to prevent the tensioner from seizing.
- Apply a small amount of Prusa lubricant to the tip of the M3x30 screw.
- Extiende el lubricante uniformemente por toda la rosca.

PASO 11 Tensioner Installation



- ✦ Push the assembly into the belt-tensioner plastic part in the printer.
 - ✦ The opening with the nut on the pulley assembly must align with the tensioning bolt.
 - ✦ Tighten the M3x30 tensioning bolt to fix the assembly in place.
-  Do not tighten the screw fully yet.

PASO 12 Belt Tensioning



- ✦ Conecta la impresora a la corriente.
- ✦ Enciende la impresora mediante el interruptor situado en la parte posterior.
- ✦ Visit the Adjusting belt tension article and tighten both the belts to the correct tension.

PASO 13 Finish



- To finish the repair, we recommend to visit the menu ***Control -> Calibrations & Tests*** and run the Selftest.
- Congratulations. Your printer is ready for use again.

[illegible]

[illegible]

[illegible]

[illegible]
